


## **MICHELIN BIB MOUSSE FITMENT RECOMMENDATIONS**

### **THE MICHELIN RECOMMENDATION**

- Michelin Bib Mousses should not be stored regularly at temperatures over 86°F, and temperatures above 104°F should be avoided all together.
- Michelin Bib Mousses are designed for off road competition use fitted to Michelin tires. The successful fitting and performance of Michelin Bib Mousse in tire brands other than Michelin cannot be guaranteed.
- Not designed for use on the public highway (NHS). The maximum speed for a tire with a Michelin Bib Mousse fitted is 80 mph.
- The date of first use of the Michelin Bib Mousse should be no later than the "To Be Fitted Before" date on the exterior of the Michelin Bib Mousse box.
- The Michelin Bib Mousse has a maximum service life of up to 6 months from first installation.



### **OPERATING MODE: DEMOUNTING A BIB MOUSSE**

- Place the wheel on a fitting cradle or support.
- Unseat the first bead and lubricate abundantly.
- Put 3 levers in position, 10 cm apart. Remove the bead by inclining the 3 levers one after the other. Keep only one lever, straighten it then turn the tire on the wheel to completely remove the bead.
- Finish removing the tire by hooking the 2nd bead with a lever.
- Extract the Bib Mousse insert from the tire.

### **OPERATING MODE: MOUNTING A BIB MOUSSE**

The rim must be in good condition. Check the spokes to prevent abnormal friction between the Bib Mousse and wheel.

- Position a rim tape inside the wheel or, failing this, a piece of adhesive tape covering the spoke nuts.
- Place the wheel on the fitting unit.
- Place the Bib Mousse gel inside the tire. We recommend applying it with a brush (Avoid getting the gel on the tire beads => Risk of rotation on the rim).
- If necessary apply vertical pressure on the tire to prise the beads apart.
- Position the Bib Mousse inside the tire.
- Lubricate the first tire bead and the part of the Bib Mousse that will be in contact with the rim (a Michelin liquid lubricant should be used).
- Make sure there is no valve on the rim.
- Put the first bead onto the rim. Start by positioning it in the rim well then use a fitting lever if necessary. Insert the Bib Mousse as far as it will go into the rim well.
- Lubricate the 2nd tire bead.
- First put the bead onto the rim using a fitting lever.
- Immobilize this lever and then use a 2nd lever around 30 cm from the first to continue inserting the bead.
- Immobilize this 2nd lever then use a 3rd one to continue positioning of the bead, etc, until the bead is fully in position.
- To seat the beads of the tire correctly against the rim flanges, it is recommended to inflate it to approximately 50 psi using a rubber TL valve. The valve is fixed on the inflation connector and simply positioned over the valve hole in the rim.